



How To Use

Assembly & Filling

1



Assembly:

Each Beer Tube is comprised of 4 basic pieces – a base, a tap, a tube and a lid. The tap will screw directly into the tube.

Each tap comes with a plastic washer. Make sure the washer is secured over the tap threads before attaching the tap to the tube. Multiple plastic washers may be used to prevent leaking and align the tap on tube.

Simply align the threads of the tap to the tube and screw in. The tap should fit tightly into the tube. Do not overtighten.

After attaching the tap to the tube, simply place the tube into the base and attach the lid to the top of the tube.

2



Filling:

Remove the tube from the base when filling.

To fill the tube, simply remove the lid and pour directly from your tap. Similar to filling a pint glass, be sure to keep the tube tilted at the proper angle to avoid unwanted foam. (Photo 1 and 2 above show both available tube styles.)

The tube, base, and tap are interchangeable to simplify the process of filling and cleaning the tubes.

If you are experiencing excess foaming during the filling process, you may need to adjust the flow pressure from your tap.

Also, be sure that your tubes and your beer lines are clean to promote less foaming.

Caution: If you are using a “medallion” lid with a logo, do not pull the lid off by the medallion piece as it may cause it to detach from the lid. Be sure to always remove the lid carefully from the top of the tube.

For additional information or questions, please contact us at
info@beertubes.com or call (614) 769-1569